
tSurvey2.0 User Manual

Content

1. An Overview of tSurvey2.0	1
1.1 Introduction	1
1.2 Installation&Uninstallation	2
2. Project	3
2.1 Project Manager	4
2.2 Project Data Manager	5
2.3 Coordinate System	6
2.4 Localization	11
2.5 Point Calibration	13
2.6 Points Database	14
2.7 Export File	16
2.8 Code Library	17
2.9 Software Settings	19
2.10 About Software	20
2.11 Grid To Ground	21
2.12 Sharing Code	22
3. Device	24
3.1 Communication	24
3.2 Rover	26
3.3 Base	30
3.4 Static	32
3.5 Inspection Accuracy	33
3.6 Pole Calibration	34
3.7 Device Information	35

3.8 Device Settings	36
3.9 Repositioning	37
3.10 Device Activation	37
3.11 Others	38
4. Survey	40
4.1 Point Survey	40
4.2 Tilt Survey	45
4.3 Detail Survey	46
4.4 Control Point	47
4.5 CAD	48
4.6 Point Stakeout	50
4.7 Line Stakeout	53
4.8 Elevation Control	55
4.9 Road Stakeout	56
4.10 PPK Survey	61
4.11 Survey Settings	61
4.12 Layers Settings	62
4.13 AR Stakeout (WiFi communication mode required)	63
4.14 Laser Survey	66
4.15 Photogrammetry (WiFi communication mode required)	68
5. Tools	71
5.1 Coordinate Converter	71
5.2 File Conversion	72
5.3 Angle Converter	73
5.4 Perimeter and Area Calculation	74
5.5 Volume Calculation	75

5.6 Correction after Measurement	76
5.7 File Sharing	77
5.8 Eccentric Point	78
5.9 Azimuth Distance	79
5.10 Point-Line Calculation	80
5.11 Three-Point Circle Center	81
5.12 Average Value Calculation	82
5.13 Spatial Distance	83
5.14 Angle Calculation	84
5.15 Intersection Calculation	85
5.16 Backward Intersection	86
5.17 Forward Intersection	87
5.18 Offset Point Calculation	88
5.19 Midpoint Calculation	89
5.20 Extension Point Calculation	90
5.21 Vertical Distance Calculation	91

1. An Overview of tSurvey2.0

1.1 Introduction

tSurvey2.0 is an engineering measurement application developed for high-precision GNSS (Global Navigation Satellite System) positioning. The development team, drawing upon years of surveying development and market experience, designed this application by integrating the usage habits of industry professionals and the operating style of Android. The result is a powerful yet user-friendly engineering measurement application that includes features such as high-precision point measurement, point and line stakeout, road design stakeout, CAD, and more. The software is characterized by its simple and user-friendly operation, easy-to-learn humanized workflow, robust road design and construction stakeout capabilities, powerful CAD mapping and stakeout functions, and a convenient user-customizable menu for feature display.

The software primarily consists of four main sections: Project, Device, Measurement, and Tools. Here is a brief overview of the basic functions within each section:

1.1.1 Project

This section is primarily focused on project configuration, data management, and software settings. It encompasses various functions, including project management, file management, coordinate systems, transformation parameters, base station translation, coordinate point database, data export, code management, software settings, and information about the software.

1.1.2 Device

This section primarily focuses on operations related to connecting high-precision GNSS instruments and configuring instrument. It includes functions such as communication settings, rover mode, base station mode, static mode, instrument information, instrument settings, repositioning, and instrument registration.

1.1.3 Measurement

This section primarily focuses on field data measurement, layout, and industry applications using GNSS positioning. It includes functions such as point measurement, partial measurement, control point measurement, CAD (Computer-Aided Design), point stakeout, line stakeout, road stakeout, and more.

1.1.4 Tools

This section primarily includes various practical tools related to field measurements. It encompasses functions such as coordinate transformation, file conversion, angle transformation, perimeter and area calculation, earthwork calculation, post-measurement correction, file sharing, eccentric point calculation, bearing and distance calculation, point-to-line calculation, three-point circle center calculation, average calculation, spatial distance, and more.

1.2 Installation&Uninstallation

Installation:

- 1、Download the tSurvey2.0 software installation package (*.apk).
- 2、Copy the tSurvey2.0 apk to your mobile device (controller). In the file manager of the controller, locate the apk and click it to install. (Subsequent version updates support online upgrades; refer to the "About Software" section for details.)
- 3、Click the tSurvey2.0 on the desktop to launch the software. (For the first time, you need to create a project; subsequently, the software will automatically open the last used project each time it starts.)

2. Project

Enter the main menu of the software, click "Project", and the corresponding functional menu will be displayed, as illustrated in Figure 2-1. The "Project" menu encompasses various functions, serving as a hub for project manager, project data manager, coordinate system, localization, calibrate point, point database, export file, code library, software setting, and about software.



Figure 2-1

The software organizes and manages all data and operations on a project basis. Upon the initial entry into the software, it is essential to create a project. Subsequent entries will automatically load the last used project. Each project is stored in a folder format under the respective directory (default location: Internal Storage -> tSurvey2.0 -> Project). Basic project information is stored in the file named "ProjectName.job," while other data is stored in the corresponding subdirectories.

2.1 Project Manager


Click "Project" -> "Project Manager", as shown in Figure 2.1-1. Project Manager includes functions such as creating a new project, importing a project, exporting a project, deleting a project, and opening a project.

Click "Project Path" to modify the project's path. The default path is in Internal Storage -> tSurvey2.0 -> Project directory.


Click "Details", as shown in Figure 2.1-2, to modify the project's basic information, coordinate system parameters, code management, and other essential attributes.

Click on "New", as illustrated in Figure 2.1-3. When creating a new project, fill in details such as the project name, whether to apply a template, and choose a code template. Click "OK." Then, input or modify the coordinate system parameters for the project, as shown in Figure 2.1-4, and click "OK" to complete the project creation.


Clicking other projects in the list will provide an option to open them, as seen in Figure 2.1-5. Long-pressing on a project in the list will reveal a delete option, as shown in Figure 2.1-6 (Note: You cannot delete a project that is currently in use).



New Import Export Details



Cancel OK



Cancel OK

Figure 2.1-1

Figure 2.1-2

Figure 2.1-3



Figure 2.1-4




Figure 2.1-5




Figure 2.1-6

2.2 Project Data Manager

Click "Project" -> "Project Data Manager", as shown in Figure 2.2. File Management includes functions such as creating a new data file and opening existing data files.



Figure 2.2

2.3 Coordinate System

Click "Project" -> "Coordinate Systems Parameter", as shown in Figure 2.3-1. The coordinate system parameters are used to calculate and convert the latitude and longitude coordinates received from GNSS devices into the flat coordinates desired by the user. During this calculation and conversion process, specific parameters need to be set, and different parameter settings will yield different conversion results. The entire process of calculation and conversion includes:

1. Raw latitude and longitude coordinates -> Spatial rectangular coordinates on the CGCS2000 ellipsoid: Utilize CGCS2000 ellipsoid parameters;
2. Spatial rectangular coordinates on the CGCS2000 ellipsoid -> Spatial rectangular coordinates on the target ellipsoid: Employ benchmark transformation parameters;
3. Spatial rectangular coordinates on the target ellipsoid -> Target latitude and longitude coordinates: Use parameters specific to the target ellipsoid;
4. Target latitude and longitude coordinates -> Projected plane coordinates: Combine target ellipsoid parameters with projection parameters;

5. Projected plane coordinates -> Target plane coordinates: Apply plane correction and vertical correction parameters.

Click "Coordinate System Parameters" and, based on actual needs, choose whether to use RTCM parameters, as shown in Figure 2.3-2.

Click "Ellipsoid Parameters" to enter the ellipsoid management, as depicted in Figure 2.3-3. Choose the required ellipsoid from the ellipsoid list.;

Click "Projections Parameters" and select the desired projection method. There are various projection methods available, such as Gauss projection, UTM projection, Transverse Mercator projection, and Double Stereographic projection, as shown in Figure 2.3-4. If using Gauss projection, input the correct central meridian, northern constant, eastern constant, projection scale, and reference latitude parameters;

Click "Seven Parameters" to enter the seven parameters editing interface, as shown in Figure 2.3-5. The transformation models include the Bursa General Algorithm, Bursa Strict Algorithm, and other transformation models;

Click "Four Parameters/Horizontal Adjustment Parameters" to enter the four parameters editing interface, as shown in Figure 2.3-6. The transformation models include four parameters and horizontal adjustment models;

Click "Vertical Control Parameters" to enter the elevation fitting parameters editing interface, as shown in Figure 2.3-7;

Click "Vertical Adjustment Parameters" to enter the vertical correction parameters editing interface, as shown in Figure 2.3-8;

Click "Plane Grid File" to enter the plane grid model file interface, as shown in Figure 2.3-9. This supports grid conversion file conversion, importing grid offset files, and correcting coordinates based on the positions of transformation points in the grid.

Click "Height Grid Correction File" to enter the elevation grid file interface, as depicted in Figure 2.3-10. This supports geodetic level file conversion, importing geodetic level files, and correcting coordinate elevations based on the positions of transformation points in the level;

Click on "Geoid File" to enter the geodetic level parameters editing interface, as shown in Figure 2.3-11. Calculation modes include bilinear interpolation, biquadratic interpolation, spline interpolation, and other calculation modes;

Click "Local Offsets" to enter the base station translation parameters editing interface, as shown in Figure 2.3-12. In small-scale operations, sometimes there is only one control point, and a translation transformation is sufficient for converting from projected plane coordinates to target plane coordinates. You can set it here. The difference between translation parameters here and base station translation calibration lies in the fact that the coordinate system parameter settings here will affect all data in the entire project. If changed, it will recalculate the conversion between latitude and longitude coordinates and plane coordinates, whereas base station translation calibration only affects the measured coordinates after calibration operation.

Click "Export" to export the current coordinate system parameters, as shown in Figure 2.3-13. In addition to manually entering coordinate system parameters, you can also click on "Apply" below to import coordinate system parameters from local files or coordinate system templates, as shown in Figure 2.3-14. Coordinate system templates include commonly used coordinate system parameters for various countries and regions, as shown in Figure 2.3-15




Figure 2.3-1




Figure 2.3-2




Figure 2.3-3




Figure 2.3-4



Figure 2.3-5






Figure 2.3-6



Cancel

OK



Cancel

OK



Cancel

OK

Figure 2.3-8

Figure 2.3-9





Figure 2.3-10

Figure 2.3-11

Figure 2.3-12






Figure 2.3-13

Figure 2.3-14

Figure 2.3-15



2.4 Localization

Click "Project" -> "Localization", as shown in Figure 2.4-1. You can import control point parameters in various formats and export control point data as files for use by third-party software. The high-precision position obtained from GNSS devices is in satellite positioning latitude and longitude coordinates. However, in actual project operations, ground plane coordinates are ultimately needed for measurement applications. If you have coordinated transformation parameters, they can directly set the coordinate system parameter values in the coordinate system section (refer to Section 2.3). If you do not have specific coordinate system parameters but have corresponding latitude and longitude coordinates and plane coordinate values, referred to as control points, this feature can be used to calculate the transformation parameters when control point data is available and apply them to project operations.

Click "Add," as shown in Figure 2.4-2. You can enter control points manually or choose to import them from the point database, as illustrated in Figure 2.4-3. In the control point list, selecting a data item allows you to modify, edit, and delete control point parameters, as shown in Figure 2.4-4.

After editing the control point parameters, calculate the transformation parameters for the control points by clicking "Convert Method," which will bring up the transformation parameter conditions setting, as shown in Figure 2.4-5. Coordinate transformation methods include plane correction, vertical correction, elevation fitting, and seven parameters. These methods can be used individually or in combination, and the calculated transformation parameters are considered usable as long as they fall within the permitted accuracy range. The plane correction model includes four parameters and horizontal adjustment, while the elevation fitting method includes weighted average, plane fitting, surface fitting, and vertical adjustment. Typically, if the working range is extensive, using the seven parameters may be necessary to meet the accuracy requirements for all control points. If the working range is relatively small, plane correction alone may achieve the required accuracy.

After configuring the calculation conditions, click on "Calculate." The results of the transformation parameter calculation and the residuals for each control point will be displayed, as shown in Figure 2.4-6. Once the transformation parameters are calculated, you can export a calculation report for project review. If the transformation parameters are qualified, you can apply them to the engineering project, enabling normal measurement operations.

Localization

Calculate Mode

Horizontal co + Elev.co

Import

Export

control point

Known Coordinates

Name

North

East

Height

Geodetic Coordinates

Coordinates Type

Latitude

Longitude

Altitude

Options

Use Horizontal Control

Use Vertical Control

Points Database

Point Library Stakeout point

Input name or code

Name North East Height

Name	North	East	Height	
PPK p3	2562922.759	441774.925	28.601	N2
▲ p2	2562922.766	441774.932	30.185	N2
▼ p1	2562921.958	441775.532	26.112	N2
▼ t9	2563061.444	441676.895	18.892	N2
▼ t8	2563064.214	441632.112	18.656	N2
▼ t7	2563148.178	441558.261	19.432	N2
▼ t6	2563154.803	441670.117	19.385	N2
▼ t5	2563103.008	441789.162	19.354	N2
▼ t4	2563014.288	441794.819	18.121	N2
▼ t3	2562917.758	441787.826	17.334	N2
▼ t2	2562936.491	441707.220	16.931	N2
▼ t1	2562960.967	441716.320	17.074	N2

Add Edit Delete Calculate

Cancel OK

IMPORT ADD OK

Figure 2.4-1

Figure 2.4-2

Figure 2.4-3

Localization

Calculate Mode

Horizontal correction + Elev_correction

No. 1 Name t1

Horizontal... 0 Vertical... 0

Use Hori... Use Use Vert... Use

No. 2 Name t2

Horizontal... 0 Vertical... 0

Use Hori... Use Use Vert... Use

No. 3 Name t3

Horizontal... 0 Vertical... 0

Use Hori... Use Use Vert... Use

Localization Settings

Convert Method

Horizontal correction + Elev_correction

Horizontal correction Model

Horizontal Adjustment

Vertical Control

Automatic Selection

Horizontal Accuracy Limit

0.1

Vertical Accuracy Limit

0.1

GPS Parameters Report

Ellipsoid Parameter

Ellipsoid Name CGCS2000

Semimajor axis 6378137

1/f 298.257

Projections Parameter

Projections Mode Transverse Mercator

Central Meridian E114°00'00"

False Northing 0

False Easting 500000

Scale Factor 1

Projection Height 0

Latitude of Origin N0°00'00"

Standard Parallel 1 N0°00'00"

Standard Parallel 2 N0°00'00"

Four-Parameter/Horizontal Adjustment

Translate Northing 15.91112

Translate Easting -38.007505

Rotation 174°54'03.0964"

Scale 46.08128383656768

Original

Save Apply

Add Edit Delete Calculate

Cancel OK

Save Apply

Figure 2.4-4

Figure 2.4-5

Figure 2.4-6

2.5 Point Calibration

Click "Project" -> "Calibrate Point", as shown in Figure 2.5-1. In the actual application process, the GNSS device obtains high-precision positioning through differential data from reference stations. Here, we recognize that the coordinates of the reference station are known. In reality, the high-precision position output by the GNSS device is the relative position of the reference station. In practical applications, in addition to some users using differential data from CORS reference stations, a considerable number of users use differential data transmitted by their own GNSS devices.

When using the self-established base station to transmit differential data, a project may involve multiple starts of the reference station. During the startup of the reference station, the startup position and coordinates of the base station may change, and the startup coordinates may not be correct. Without calibration, the coordinates obtained using the differential data from these base stations may be incorrect. Therefore, when the mobile station receives new differential data from the base station for measurement operations, translation calibration is needed to ensure that the coordinates obtained by the software match the coordinates obtained from the last connected base station.

After the startup coordinates or position of the base station change, it is necessary to use a known position to calibrate the coordinates correctly.

Click "Base Point Calibration," as shown in Figure 2.5-2. Click  and select a known point from the point database (using the coordinates measured by the last base station at a specific location), then click "Calculate" and apply to complete the calibration process.

Click "Marker Point Calibration," as shown in Figure 2.5-3. Click  and select a known point from the point database (using the coordinates measured by the last base station at a specific location). Then, place the device at the location of the known point, click  to measure a new point," and calculate the deviation value. Click "Apply," and the coordinates received by the software will now match the coordinates measured in the last session.

If there is a notification about changes in base station coordinates and you are receiving differential signals from a self-established base station, it indicates the need for base station translation recalibration. In such cases, it is advisable to perform the base station translation

calibration again to ensure accurate coordination between the received coordinates and the actual ground coordinates.

Note: CORS stations are Continuously Operating Reference Stations where both the position and startup coordinates remain unchanged. If using differential data from CORS stations, even if the received coordinates may change, the obtained coordinates are still correct, and there is no need for translation calibration.

Calibrate Point

Base Point Calibration

Marker Point Calibration

dX: 0

dY: 0

dH: 0

Calibrate Point

Known Point Coordinates

North: 2562960.967

East: 441716.32

Height: 17.074

Current Base Coordinates

Latitude: 23°09'54.484426"

Longitude: 113°25'51.930324"

Altitude: 56.624

Antenna Parameters: 0m, Height to phase center

Result

Shift dX: 21.646

Shift dY: -28.374

Shift dZ: -39.55

Calibrate Point

Known Point Coordinates

North: 2562960.967

East: 441716.32

Height: 17.074

Current WGS84 Coordinates

Latitude: 23°09'53.953632"

Longitude: 113°25'52.998492"

Altitude: 28.409

Result

Shift dX: 37.975

Shift dY: -58.757

Shift dZ: -11.335

Clear OK Base Information Calculate Apply

Figure 2.5-1

Base Information Calculate Apply

Figure 2.5-2

Cancel Apply

Figure 2.5-3

2.6 Points Database

Click "Project" -> "Points Database", as shown in Figure 2.6-1. Here, you can view and manage point data in the project, including functions such as adding, editing, deleting, importing, etc.

Click , as shown in Figure 2.6-2, to switch the display style of point information.

Click "Add," as shown in Figure 2.6-3. You can manually enter the point name, code, and corresponding coordinates;

Click "Import," as shown in Figure 2.6-4. Choose the file format for importing point data, then proceed to select the data file to complete the data import process;

Select the point, click "Edit," as shown in Figure 2.6-5, and you can edit and modify the name and code of the point;

Click  , as shown in Figure 2.6-6, to perform point type filtering.

Clicking  will pop up operations, as shown in Figure 2.6-1, where you can perform batch deletion, data statistics, sorting, and other functions as needed;




Figure 2.6-1 shows the Points Database screen. The table lists points with columns: Name, North, East, and Type. A context menu is open over the first point (p3). The menu options are: Batch Operation, Deleted points, and Statistics. The table data is as follows:

Name	North	East	Type
p3	2562922.759	441774.92	
p2	2562922.766	441774.93	
p1	2562921.958	441775.53	
t9	2563061.444	441676.895	18.892 N2
t8	2563064.214	441632.112	18.656 N2
t7	2563148.178	441558.261	19.432 N2
t6	2563154.803	441670.117	19.385 N2
t5	2563103.008	441789.162	19.354 N2
t4	2563014.288	441794.819	18.121 N2
t3	2562917.758	441787.826	17.334 N2
t2	2562936.491	441707.220	16.931 N2
t1	2562960.967	441716.320	17.074 N2

At the bottom are buttons: IMPORT, EXPORT, and ADD.

Figure 2.6-1




Figure 2.6-2 shows the Points Database screen. The table lists points with columns: Name, North, East, and Type. A context menu is open over the first point (p3). The menu options are: Batch Operation, Deleted points, and Statistics. The table data is as follows:

Name	North	East	Type
p3	2562922.759	441774.92	PPK Point
p2	2562922.766	441774.93	Control point
p1	2562921.958	441775.53	Survey point
t9	2563061.444	441676.895	Input point
t8	2563064.214	441632.112	Input point

At the bottom are buttons: IMPORT, EXPORT, and ADD.

Figure 2.6-2




Figure 2.6-3 shows the New point dialog box. It has fields for Name (p4), Property type (Input point), Coordinates Type (Local Coordinate), and a Photo And Sketch section. At the bottom are buttons: Cancel and OK.

Name	p4
Property type	Input point
Coordinates Type	Local Coordinate
North	
East	
Height	
Code	
Photo And Sketch	

At the bottom are buttons: Cancel and OK.

Figure 2.6-3



Points Database					
Point Library			Stakeout point		
Input name or code		Search and Filter			
Name	North	East	Height	Code	
PPK p3	2562922.759	441774.925	28.601	N2	
▲ p2	2562922.766	441774.932	30.185	N2	
📍 p1	2562921.958	441775.532	26.112	N2	
🔗 t9	2563014.288	441794.819	18.121	N2	
🔗 t8	2562917.758	441787.826	17.334	N2	
🔗 t7	2562936.491	441707.220	16.931	N2	
🔗 t6	2562960.967	441716.320	17.074	N2	
🔗 t5					
🔗 t4					
🔗 t3					
🔗 t2					
🔗 t1					

Figure 2.6-4

Figure 2.6-5

Figure 2.6-6

Points Database					
Point Library			Stakeout point		
Input name or code		Search and Filter			
Name	North	East	Height	Code	
PPK p3	2562922.759	441774.925	28.601	N2	
▲ p2	2562922.766	441774.932	30.185	N2	
📍 p1	2562921.958	441775.532	26.112	N2	
🔗 t9	2563014.288	441794.819	18.121	N2	
🔗 t8	2562917.758	441787.826	17.334	N2	
🔗 t7	2562936.491	441707.220	16.931	N2	
🔗 t6	2562960.967	441716.320	17.074	N2	
🔗 t5					
🔗 t4					
🔗 t3					
🔗 t2					
🔗 t1					

Point Type Filter

- Survey point
- Control point
- Input point
- Calculate Point
- Base Point
- CAD point
- PPK Point

OK

2.7 Export File

Click "Project" -> "Export File", as shown in Figure 2.7-1. Choose the type, file format, and angle format for exporting data as needed. Click on "Export File Manage," as shown in Figure 2.7-2, choose the file format for exporting data, and click "OK." Click on "User-Defined Format," as shown in Figure 2.7-3, to manually create and edit the file format for exporting data.




Figure 2.7-1




Figure 2.7-2



Figure 2.7-3

2.8 Code Library

Click "Project" -> "Code Library", as shown in Figure 2.8-1. The encoding library predefines the coding attributes for field-collected points, allowing for quick filling of code values through descriptive and intuitive selections;

Click to the right of the code library name, as shown in Figure 2.8-2. Here, you can import, add, and delete code file names;

Click to the right of the group name, as shown in Figure 2.8-3. Here, you can add, edit, and delete code library group names;

Select a group and click "Add," as shown in Figure 2.8-4, to manually enter the name and code;

Select a code and click "Edit," as shown in Figure 2.8-5, to edit the name and code;

Select a code and click "Delete," as shown in Figure 2.8-6, to delete the code;

Click "Close" to return to the main project interface.

← Encoding Library

Code library name	Test	<input type="button" value="Edit"/>
Group Name	whole	<input type="button" value="Edit"/>
test1		
t1		

← Encoding Library File Management

Serial number	Code library name
1	CASS
2	Test

← Group name management

1	T1
---	----

Add Edit Delete Close Import Add Delete Close

Figure 2.8-1

Add Edit Delete Close Import Add Delete Close

Figure 2.8-2

Add Edit Delete Close

Figure 2.8-3

← Addcode

Group Name	T1
Name	
code	

← Editcode

Group Name	T1
Name	test1
code	t1

← Encoding Library

Code library name	Test	<input type="button" value="Edit"/>
Group Name	T1	<input type="button" value="Edit"/>

Cancel OK

Figure 2.8-4

Cancel OK

Figure 2.8-5

Add Edit Delete Close

Figure 2.8-6

2.9 Software Settings

Click "Project" -> "Software Settings", which includes settings for system, speech, storage, and shortcuts.

System: As shown in Figure 2.9-1, this includes settings for language, text encoding, angle display format, length units, coordinate display order, map display, interface style, and more;

Speech: As shown in Figure 2.9-2, this includes settings for layout tolerance, volume, voice prompts, solution status, and other sound-related configurations;

Storage: As shown in Figure 2.9-3, this involves settings for storing conditions such as terrain points, control points, fast points, continuous points, etc.;

Shortcut Keys: As shown in Figure 2.9-4, this section allows you to predefine functions triggered by physical keyboard shortcuts on the device. You can add shortcuts, choose the function to define a shortcut for, set the shortcut value, and quickly trigger the corresponding function during measurement applications.




Figure 2.9-1




Figure 2.9-2




Figure 2.9-3




Figure 2.9-4

2.10 About Software

Click "Project" -> "About Software", as shown in Figure 2.10-1, to view the software's version information and registration authorization details.

Click "Check for New Versions". If there is a new version, a popup with information about the update will appear. Click "Update" to install the latest version of the software. If there is no new version, a message will indicate that the software is already up to date.

Click "Software Registration", and it will take you to the software registration interface, as shown in Figure 2.10-2. Here, you can view the activation ID and expiration date.

For the first-time software installation, click on "Online Activation." This allows you to activate the software for free for three month directly.

Click on "Manual Code Activation", as shown in Figure 2.10-3. Here, you can input the authorization code or scan the QR code to activate the software.

If you need to change to a new controller, you can click "Transfer Registration Code" in the old controller. After that, enter the transferred activation code in the software registration of the new controller to activate the software.



Figure 2.10-1

Figure 2.10-2

Figure 2.10-3

2.11 Grid To Ground

Click "Project" ->"Grid To Ground" , as shown in Figures 2.11-1 and 2.11-2. This function calculates the grid correction factor at a reference point, which is then applied to other points in the coordinate point database. This allows the GNSS measured points to match with the total station points. The corrected coordinates can be exported during data export.



Figure 2.11-1




Figure 2.11-2

2.12 Sharing Code

Click on "Project" -> "Sharing Code" , as shown in Figure 2.12-1. On one controller, select the project or files you wish to share. Once the sharing is complete, as shown in Figure 2.12-2, other controllers can enter the share code or scan the QR code in the software's main interface to receive the shared files, as shown in Figure 2.12-3.

Note: Whether sharing or receiving files, the controller must first be connected to the internet.




Figure 2.12-1




Figure 2.12-2




Figure 2.12-3

3. Device

On the software's main menu, click "Device", as shown in Figures 3-1 and 3-2. The "Device" section includes functions such as Communication, Rover, Base, Static, Device Information, Device Settings, Restart Positioning, and Device Activation.



Figure 3-1

Figure 3-2

The software's data measurement collection and application are based on high-precision GNSS positioning. Before starting the operation, it is necessary to establish communication with the GNSS positioning device. The software retrieves high-precision location data from the device, and certain conditions must be met for the device to obtain high-precision location. This involves configuring parameters for the device

3.1 Communication

Click "Device" -> "Communication" to enter the communication settings, as shown in Figure 3.1-1. Select the instrument type ("RTK"), communication mode ("Bluetooth"), then click "Search," as shown in Figure 3.1-2, to view the Bluetooth device list. Select the corresponding device serial number, click "Connect" to complete the device connection, as shown in Figure 3.1-3 After

successfully connecting the device, it will directly return to the menu, as shown in Figure 3.1-4. To re-enter communication settings, as shown in Figure 3.1-5, clicking "Stop" will disconnect the device connection. Clicking "Debug" allows you to view the data communication between the software and the device, as shown in Figure 3.1-6.

- 1、Communication modes include Bluetooth, Port, TCP client, etc;
- 2、Click "Search" to enter Bluetooth search and selection. Click on the corresponding device serial number to choose the device you want to connect to;
- 3、After successfully connecting the device, click "Debug" to view the data communication between the software and the device. You can also send debug commands to the device to troubleshoot and analyze location-related issues.




Figure 3.1-1




Figure 3.1-2




Figure 3.1-3



Figure 3.1-4




Figure 3.1-5



Figure 3.1-6

3.2 Rover

Click "Device" -> "Rover", as shown in Figure 3.2-1. GNSS positioning devices can calculate the position coordinates by receiving satellite signals, normally, due to atmospheric effects on signals, the positioning device can only obtain coordinates with a single-point solution, resulting in low accuracy. To ensure high-precision positioning with GNSS, in addition to the GNSS device itself receiving and calculating positions from satellite signals, it also needs to receive signals from another nearby fixed-position GNSS device. This second device's signal serves as the reference signal. Since the atmospheric effects on signals are generally consistent within a certain area, with the known coordinates of the reference signal, the two sets of GNSS can calculate high-precision positions. The GNSS device with a fixed position is called the reference station, while the one with a variable position is called the mobile station. The data transmitted from the reference station to the mobile station is referred to as differential data, and the data transmission method is known as a data link. The Mobile Station Mode setting configures the GNSS device as a mobile station, establishing certain parameters to transmit the reference station's GNSS satellite signals to the GNSS device through a specific method, allowing the GNSS device to achieve high-precision positioning.

In addition to configuring the differential data transmission, you can also set basic information for GNSS, such as the elevation cutoff angle, differential delay, and whether to enable PPK (Post-Processed Kinematics), as shown in Figure 3.2-1. Setting the elevation angle below a certain value will exclude the reception of satellite signals at low angles. In situations with poor signal quality at low angles, this can be beneficial for precision calculation. PPK parameters involve recording raw observational data from GNSS receivers and using post-processing algorithms to calculate high-precision coordinates.

Differential data parameter settings are primarily for configuring the transmission of differential data from the reference station to the current device through a specific method. This provides necessary conditions for the device to calculate high-precision coordinates. Data transmission methods mainly include Phone Internet, Device Internet, Internal Radio, and other options:

1、Phone Internet: As shown in Figure 3.2-1, it refers to obtaining differential data through the network of the device where the software is located. The data is acquired from a specified server address according to a certain protocol, and then transmitted to the device through the software's communication connection for high-precision calculation. Click the  at the right of CORS setting to enter CORS settings, as indicated in Figure 3.2-2. Here, you can directly select, edit, or delete existing CORS servers, or manually add CORS server, as shown in Figure 3.2-3. After correctly configuring the server address, retrieve the mount point list, as shown in Figure 3.2-4, and select the corresponding Mount point to obtain differential data. Click "Start," and if the configuration is correct, the data reception progress bar will start moving. If the progress bar shows no data, check whether the configuration is correct.

2、Device Internet: As shown in Figure 3.2-5, it refers to obtaining differential data through the SIM card network of the GNSS device. This is done according to a certain protocol from a specified server address for high-precision calculation. The connection mode involves the transfer protocol for differential data, typically using NRTIP, TCP client, etc. Enter server IP, port, username, and password. The SIM network is a dedicated network, and APN parameters need to be configured, as shown in Figure 3.2-6. CORS settings are similar to Phone Internet settings. After correctly configuring the server address, retrieve the mount point list and select the corresponding mount point to obtain differential data. Mount points can be obtained through the device network, or if a mobile phone has a network, it can also be obtained through the corresponding network of the mobile phone.

3、Internal Radio: As shown in Figure 3.2-7, it refers to obtaining differential data through the built-in radio of the GNSS device. According to a certain protocol and frequency, the device receives differential data from the radio for high-precision calculation. In this case, it is necessary to ensure that the protocol and frequency of the built-in radio match those of the transmitting radio to receive the radio data normally. If the frequency of the channel does not match the channel frequency of the transmitting radio, you can click "Set Radio Frequency" to modify the frequency corresponding to each channel of the radio, as shown in Figure 3.2-8.

4、XLINK: As shown in Figure 3.2-9, it is a differential forwarding system built on the CORS network of Qianxun/Sixents/China Mobile. After configuring the XLINK data link, the device can access the differential data normally as long as it can connect to the Internet, without the need for the user to manually enter CORS account information.

Note: Every data link has the baseline coordinate change prompt enabled by default. This is because receiving incorrect base station signals may lead to inaccurate coordinates, and it is recommended to check and confirm.




Figure 3.2-1




Figure 3.2-2



Figure 3.2-3



Figure 3.2-4



Figure 3.2-5




Figure 3.2-6




Figure 3.2-7



Figure 3.2-8




Figure 3.2-9

3.3 Base

Click "Device" -> "Base", as shown in Figure 3.3-1. This function allows the GNSS device to act as a base station, sending satellite information data in a certain way to provide high-precision calculation conditions for the receiving rover station. The main station as a base station needs to set parameters such as startup conditions, startup mode, and data broadcast parameters.

Note: During the base station startup period, the device is not allowed to move; otherwise, it may cause errors in the coordinates calculated by the rover station.

Startup conditions include parameters such as base station ID, differential data format, elevation mask angle, PDOP limit, etc. Click "Advanced," as shown in Figure 3.3-2, to configure parameters such as elevation mask angle and PDOP limit. The differential data formats include commonly used formats such as CMR, RTD, RTCM23, RTCM30, RTCM32, RTCM33;

The startup mode includes using a single-point coordinate and specifying the base station coordinate:

1、Using a single-point coordinate: This means that the GNSS device outputs differential broadcast data based on the current position (with low accuracy) as the startup coordinate;

2、Specifying the base station coordinate: This involves the user specifying the coordinates based on the location where the device is set up. The user pre-knows the coordinates of this position, and these coordinates are used as the startup coordinates for outputting differential broadcast data.

Click  to measure a point, or click  to measure a point in real-time or select a coordinate value from the coordinate point library, as shown in Figure 3.3-3.

Data broadcast mainly involve how the base station, after startup, outputs the differential data for the mobile station to receive and use. The main methods include the Device Internet, Internal Radio, external radio, etc. Settings are similar to those for the rover station, with the following differences:

1、The Internal Radio has a transmission power, and the higher the transmission power, the farther the effective range, but it also consumes more power;

2、For the Device Internet NTRIP protocol, the base station sets the starting transmission base station access point, as shown in Figure 3.3-1, while the rover station obtains a list of mount points and selects the corresponding base station mount point for connection;

3、 The base station uses an external radio for differential data broadcast, as shown in Figure 3.3-4. The baud rate must match that of the connected external radio;

4、 CORS settings refer to the corresponding configuration of the rover station's data link




Figure 3.3-1



Figure 3.3-2




Figure 3.3-3




Figure 3.3-4

3.4 Static

Click "Instruments" -> "Static", as shown in Figure 3.4-1. This feature is designed to store the satellite's raw observation data from the GNSS device into a designated disk file, recording observational data over a period for later use with static post-processing software to calculate high-precision coordinates. It is typically used for control point collection. To initiate static mode, you need to set the point name for the static file, as well as conditions for recording such as PDOP limit, elevation cutoff angle, collection interval, antenna parameters, and file format, etc, as shown in Figure 3.4-2.

Click "Start" to start static collection, as shown in Figure 3.4-3, and click "Stop" to end static collection. In the status, information such as record status, start time, number of epochs, and record file name is displayed.

Note: During static recording, device movement is not allowed, as it may result in inaccuracies in the coordinates calculated during post-processing.

← Static mode settings

Options Settings

Name	4969
PDOP limit	3.0
Cut-off angle	10
Collection Interval	1Hz
Observation time	30min
File Format	GNSS
Execute after completion	Switch to Rover

Antenna Parameters

Antenna Measured Height	1.8
Antenna Measurement Type	Vertical height
Antenna Height	1.86

Status

Record Status	Non static mode
Start Time	
End Time	

Advanced Start

← Static mode settings

Options Settings

Name	4969
PDOP limit	3.0
Cut-off angle	10
Collection Interval	1Hz
Obs time	GNSS
File	RINEX302
Exe	RINEX303
Ante	RINEX304
Ante	RINEX305
Antenna Measurement Type	Vertical height
Antenna Height	1.86

Status

Record Status	Non static mode
Start Time	
End Time	

Advanced Start

← Static mode settings

Options Settings

Name	4969
PDOP limit	3.0
Cut-off angle	10
Collection Interval	1Hz
Observation time	30min
File Format	GNSS
Execute after completion	Switch to Rover

Antenna Parameters

Antenna Measured Height	1.8
Antenna Measurement Type	Vertical height
Antenna Height	1.86

Status

Record Status	Static mode, writing file
Start Time	20240104-033132
End Time	20240104-040110
Epoch number	68
Record file	4969-03-20240104-033132.gnss

28min

Advanced Stop

Figure 3.4-1

Figure 3.4-2

Figure 3.4-3

3.5 Inspection Accuracy

Click "Instruments" -> "Inspection Accuracy", as shown in Figures 3.5-1, 3.5-2, and 3.5-3. This feature involves using the inertial navigation measurement function to collect data from inclined measurement points at a fixed location. It calculates the maximum coordinate differences among the collected points to assess the accuracy of the device when utilizing the inertial navigation measurement function.

Note: This function can only be used when the instrument has achieved a fixed solution and the inertial navigation convergence is completed.






Figure 3.5-1

Figure 3.5-2


Figure 3.5-3

3.6 Pole Calibration

Click on "Device" -> "Calibrate Sensor", as shown in Figures 3.6-1, 3.6-2, and 3.6-3. If the accuracy check reveals poor results, you can use the collimation pole calibration function to correct the measurement errors caused by the curvature changes of the pole.

Pole calibration needs to be performed only once for the same instrument and the same pole. Each device is calibrated before leaving the factory, and if the pairing remains unchanged, there is no need to perform pole calibration again.


Calibrate Sensor	
Antenna Height	1.86(Pole Height1.8m)
GNSS:FIXED(Ready)[1] HR:0.006 VR:0.013	
INS:(1.04,-142.25)Inertial navigation convergence completed	
Progress:Calibration	



In the INS inertial navigation convergence state, while keeping the bottom position of the alignment rod unchanged, shake it back and forth to collect 50 points, then rotate it 90 degrees according to the prompts, and then shake it back and forth to collect 50 points until all four directions are calibrated.

Calibrate the centering rod

Calibrate Sensor	
Antenna Height	1.86(Pole Height1.8m)
GNSS:FIXED(Ready)[1] HR:0.005 VR:0.011	
INS:(2.66,7.06)Inertial navigation convergence completed	
Progress:Tilt measurement installation angle estimation stage 3	



In the INS inertial navigation convergence state, while keeping the bottom position of the alignment rod unchanged, shake it back and forth to collect 50 points, then rotate it 90 degrees according to the prompts, and then shake it back and forth to collect 50 points until all four directions are calibrated.


Close

Figure 3.6-1

Figure 3.6-2

Figure 3.6-3

Calibrate Sensor	
Antenna Height	1.86(Pole Height1.8m)
GNSS:FIXED(Ready)[1] HR:0.005 VR:0.011	
INS:(1.48,-173.28)Inertial navigation convergence completed	
Progress:Tilt measurement installation angle estimation completed	



In the INS inertial navigation convergence state, while keeping the bottom position of the alignment rod unchanged, shake it back and forth to collect 50 points, then rotate it 90 degrees according to the prompts, and then shake it back and forth to collect 50 points until all four directions are calibrated.

3.7 Device Information

Click "Device" -> "Device Information", as shown in Figure 3.7. Here, you can view basic information about the GNSS device, including its operating mode, device serial number, firmware version, battery status, expiration time, satellite systems, antenna parameters, and more.



Figure 3.7

3.8 Device Settings

Click "Device" -> "Device Settings", as shown in Figure 3.8-1. Here, you can choose the output frequency of positioning and inertial navigation data, toggle device voice, and switch the WIFI mode. When operating as a client, you can connect to an external hotspot to access the network, as illustrated in Figure 3.8-2. (Note: The device currently supports only 2.4G external hotspots.)

Click "Factory Reset" to restore the device to factory settings.

Click "VPN Settings" to enter the VPN settings. ZXVPN can establish a virtual local network, connecting the device to the server. This allows for remote technical support and services through WEBUI access in the background. Before connecting to the ZXVPN server, the device itself must have internet access (insert a SIM card or connect to an external hotspot). Click "Default," as shown in Figure 3.8-3, and then click "Apply."




Figure 3.8-1

Figure 3.8-2

Figure 3.8-3

3.9 Repositioning

Click "Device" -> "Restart Positioning", and you can directly clear the mainboard ephemeris, reset the positioning engine of the GNSS device, achieving the effect of repositioning.


3.10 Device Activation

Click "Device" -> "Device Activation", as shown in Figure 3.10, to view the device serial number and expiration date. If the GNSS device has expired, you can obtain the registration code from the dealer and authorize the device registration here.



Figure 3.10

3.11 Others



1、Click the in the software's top title bar to access the communication settings, as shown in Figure 3.1-5.



2、Click the in the software's top title bar to enter the rover station settings, as shown in Figure 3.2-1.

3、Click the "Advanced" button in the lower-left corner of the rover station, base station, or

static mode, entering the advanced settings, as shown in Figure 3.3-2. Use the buttons to enable or disable the satellite systems of the GNSS device.



4、Click the in the software's top title bar to view the device's output positioning information, base station information, and star chart information, as shown in Figure 3.11-1, Figure 3.11-2, Figure 3.11-3, and Figure 3.11-4. Since the differential data does not transmit the antenna parameters of the base station and only transmits the phase center coordinates of the base station's transmission, to obtain the ground coordinates corresponding to the base station's startup, you can input the antenna parameters corresponding to the base station.

← Position Information

Position Information		Base Information		S
FIXED		AGE: 1		
HRMS	0.006	VRMS	0.01	
North	2562922.768			
East	441774.929			
Height	28.383			
Latitude	N23°09'53.9538"			
Longitude	E113°25'52.9984"			
Altitude	28.383			
Satellite Number		40/41		
BDS	19	GPS	9	
GLN	6	GAL	6	
QZSS	0	SBAS	0	
Speed	0.003	Heading	271.05	
HDOP	0.7	VDOP	1.8	
UTC time	2023-12-01 09:40:00.000			
Local time	2023-12-01 17:40:00.044			

Figure 3.11-1

← Position Information

Information		Base Information		SAT Map
Base ID	0			
Base Latitude	N23°09'54.4844"			
Base Longitude	E113°25'51.9303"			
Base Altitude	56.624			
Altitude	56.564			
North	2562939.209			
East	441744.611			
Height	56.564			
Base_Distance	44.568			

BASE ANTENNA
PARAMETERED

SAVE

Figure 3.11-2




Figure 3.11-3

← Position Information

Base Information		SAT Map		List of satellites
Base Information		SAT Map		List of satellites
<input checked="" type="checkbox"/> BDS <input checked="" type="checkbox"/> GPS <input checked="" type="checkbox"/> GLN <input checked="" type="checkbox"/> GAL <input checked="" type="checkbox"/> QZSS <input checked="" type="checkbox"/> SBAS <input checked="" type="checkbox"/> IRNSS				

Figure 3.11-4

4. Survey

In the software's menu, click the corresponding "Survey", as shown in Figure 4-1. The survey functions include point survey, detail survey, control point survey, CAD, point stakeout, line stakeout, road stakeout, and more.



Figure 4-1

In the software, the "Project" section is used for project data management and parameter configuration, preparing necessary conditions for field measurements, and exporting measurement results. The "Device" section is essential for the software to obtain high-precision positions. The "Survey" section is the primary function of the software, addressing questions related to what to do and how to do it using high-precision coordinates.

4.1 Point Survey

Click "Survey" -> "Point Survey", as shown in Figure 4.1-1. Measure and store the location output by the GNSS device into the point database according to certain precision limiting conditions. In the Point Survey menu, the top title bar displays basic information about the current location

output by the GNSS device, including the current solution status, differential delay, HRMS, VRMS, and the number of received satellites. Below the title bar is the status bar displaying other important information, and the displayed content can be set according to user preferences in the settings. In the Point Survey, it defaults to displaying North, East, Height coordinates, and base station information. The middle area shows measurement data plotting information, and you can also set to display online maps.



In the upper-left corner of the plotting area, the  represents the map orientation, making it convenient for users to determine direction when needed. In the lower-left corner of the plotting



area, the scale of the drawing is displayed, and you can click the  or  on the right to zoom in or out on the drawing scale. Below the plotting area are the displays of the functionality collected, and these functional menus can also be customized in the settings according to the user's needs to quickly operate certain functions here.



In the lower-right corner of the plotting area, the  is the trigger button for initiating measurement and collection. This button can be moved to a more convenient location based on the user's habits. Clicking the button initiates the measurement function, as shown in Figure 4.1-2. You can input a point name and code, and by clicking the , you can choose a preset code from the code library, facilitating quick filling of attributes for the feature. If there are many codes in the code library, the codes used more frequently will be displayed at the beginning for the user's quick selection

Below the plotting area are the measurement type selection, entrance to the coordinate point library, antenna height settings, and the tools menu.

Clicking "Topo Point," as shown in Figure 4.1-3, will display four types: Topo Point, Control Point, Quick Point, and Auto Point. You can choose the corresponding point type for measurement based on your actual needs.

Click on "Points Database" to enter the point library, as shown in Figure 4.1-4. Here, you can view information about the measured points.



Click the  to edit antenna height, as shown in Figure 4.1-5. Antenna height settings are used to subtract the antenna height from the phase center coordinates of GNSS to obtain the actual location of the ground measurement target. If the antenna information is incorrect, you can click

antenna parameters to select the correct antenna type(used when GNSS devices do not output antenna information or when using an external antenna).

Click "Tools," as shown in Figure 4.1-6, to quickly operate certain functions from the menu based on your needs. You can also add or remove functions from the toolbar in the settings according to your preferences.



Click the , as shown in Figure 4.1-7, to enter the measurement settings. Here, you can set the limiting conditions for measurement collection, such as status limits, HRMS limits, VRMS limits, PDOP limits, delay limits, etc. You can adjust these limitations based on the accuracy requirements of your tasks. Setting the smoothing point count averages multiple positioning points to improve accuracy.

Additionally, you can set default point names and default codes. The information bar allows you to customize the display of status information, focusing on the details you find most important, as shown in Figure 4.1-8. The toolbar allows you to display commonly used functions for quick and easy access during operations. This includes features such as automatic centering of measurement points, toggling the map, compass mode, screen point selection, CAD text, coordinate transformation, perimeter and area calculation, CAD background color, and more. Clicking the icons in the toolbar triggers the corresponding functions, as shown in Figure 4.1-9.



Click the  to automatically center the current location on the screen. Click  to display all current measurement points on the screen.



Click , as shown in Figure 4.1-10, to toggle the tilt measurement on/off.



Click , as shown in Figures 4.1-11 and 4.1-12, to choose the desired online map for display.




Figure 4.1-1




Figure 4.1-2




Figure 4.1-3



Figure 4.1-4



Figure 4.1-5




Figure 4.1-6




Figure 4.1-7



Figure 4.1-8




Figure 4.1-9




Figure 4.1-10



Figure 4.1-11



Figure 4.1-12

4.2 Tilt Survey

The IMU function requires the device to have a tilt module. Devices equipped with this function can achieve:

1. Ensuring accuracy within 2cm in a tilt range of up to 60 degrees;
2. The calibration process is straightforward, requiring only shaking the pole back and forth in place;
3. Supports pole calibration to eliminate measurement errors caused by pole curvature, as explained in Section 3.6.

Click "Survey" -> "Point Survey" to enter the point survey page. Click the top-left corner



for turning on tilt measurement. When it is turned on, the icon appears as . Follow the prompts that appear, as shown in Figure 4.2-1, and enter the antenna height (height of the pole) based on the actual situation.

At this point, the device needs to be in a fixed solution. Refer to the animated guide that appears, as shown in Figure 4.2-2. Shake the pole back and forth for 5-10 seconds, then rotate it 90°,



and continue shaking it back and forth. Repeat this process until the icon changes to , as shown in Figure 4.2-3. Now you can proceed with tilt measurement.




Figure 4.2-1



Figure 4.2-2




Figure 4.2-3

4.3 Detail Survey

Click on "Survey" -> "Detail Survey", as shown in Figure 4.3. This function is similar to point survey but without the graphical interface of point survey, providing a more concise and intuitive display of the information needed for measuring and collecting points. Below the interface are the entrances to the point database, measurement setting, and antenna setting.




Figure 4.3

4.4 Control Point

Click on "Survey" -> "Control Point", as shown in Figure 4.4-1. Sometimes it is necessary to measure a point with very high accuracy. Collecting this measurement point requires multiple device resets, with the requirement of achieving a fixed solution for a certain period before collection. Moreover, many points need to be collected. Through a certain calculation method, points with significantly deviated values from the average are excluded, and the basic optimal values are taken to obtain an average with high precision. Points measured in this way have a high level of accuracy assurance, and we refer to such points as control points. In the control point interface, the middle area displays all coordinate points collected for this control point in real-time. You can see the graphical distribution of measurement points for this control point, providing a way to judge the accuracy of the control point to some extent. Above the graph are the point library and measurement setting;

Measurement setting, as shown in Figure 4.4-2, not only involves setting collection restriction conditions but also controlling the collection parameters for control points, such as smoothing point count, smoothing interval, and repetition count.

After completing the control point measurement, a measurement result page will appear, as shown in Figure 4.4-3. It displays the measurement analysis and results for the control point, including observation time, pass rate, and whether the control point meets the accuracy requirements.




Figure 4.4-1




Figure 4.4-2



Figure 4.4-3

4.5 CAD

Click "Survey" -> "CAD", as shown in Figure 4.4-1. The CAD involves CAD graphic display, drawing icons such as lines, polylines, arcs, polygons, and graphic calculations. It also includes the import and export of DXF and DWG graphics, layer management, and layout operations on various CAD graphics.



Figure 4.5-1

Figure 4.5-2

Figure 4.5-3







Figure 4.5-4

Figure 4.5-5

Figure 4.5-6



Figure 4.5-7




Figure 4.5-8




Figure 4.5-9

4.6 Point Stakeout

Click "Survey" -> "Point Stakeout" entering the stakeout point library, as shown in Figure 4.6-1.

1. Stakeout refers to finding the location of a point on-site when the coordinates of the point are known. The pending stakeout points display both unstaked and staked points. Clicking a staked point allows for editing, viewing details, stakeout, and deletion, as shown in Figure 4.6-2. The pending stakeout points are part of the point library, and the addition, removal, import, and export operations for staked points are the same as for points library. Removing a point from pending stakeout does not actually delete the point in the point library. Stakeout can also be performed by selecting points from the coordinate points (all points in the coordinate point library). After selecting points for stakeout, enter the stakeout interface, as shown in Figure 4.6-3.



Click  to enter the stakeout setting, as shown in Figure 4.6-4. Here, you can set parameters such as the alert range, stakeout tolerance, and choose the reference azimuth according to the cardinal directions (east, south, west, north) or relative directions (front, back, left, right). Additionally, you can configure voice prompts.

The layout of the stakeout menu is similar to the point survey menu, with some differences. The status bar displays the deviation values in the east, south, west, and north directions from the target. The compass is aligned with the current position. In addition to the measurement type, coordinate point library, antenna height, and tools at the bottom of the drawing area, there are also functions such as stakeout the nearest point, stakeout the previous point, and stakeout the next point.。

Click "Nearest," as shown in Figure 4.6-5, to stakeout the nearest point.

Click , as shown in Figure 4.6-6, to manually add stakeout points at any time.

If you want to reach the target point more quickly:

For users with a good sense of direction who can distinguish between east, south, west, and north in real-time fieldwork, you can directly observe the continuous connection between the current location point and the target point in the stakeout compass display. Walk in the direction indicated to reach the target point. Refer to Figure 4.6-3, where walking southwest will lead to the target point Pt4.

If the user has difficulty distinguishing between east, south, west, and north, you can rely on the orientation arrow at the current location. The arrow points in the same direction as the controller when it is flat. As shown in Figure 4.6-3, if the controller points south, rotate the controller until its direction aligns with the line connecting the current point and the target point. Once aligned, follow the direction indicated by the controller to reach the target point.



Figure 4.6-1




Figure 4.6-2




Figure 4.6-3




Figure 4.6-4




Figure 4.6-5




Figure 4.6-6

4.7 Line Stakeout

Click "Survey" -> "Line Stakeout", as shown in Figure 4.7-1, to enter the line stakeout menu. Line stakeout involves taking pre-designed straight lines stored in a line database and staking them out in the field. You can stake out the straight line in real-time for distances, offsets, height differences, and more. Additionally, you can divide the straight line into points at regular intervals and stake out each point individually.

For line database management, you can add, edit, or delete line data. To create a new straight line, as shown in Figure 4.7-2, enter the line name and set the starting and ending coordinates. Create the straight line using the starting point's mileage, azimuth, and length.

Select the line list to edit, insert, delete, or stake out the straight line, as shown in Figure 4.7-3

Click "OK" to enter the line stakeout setting, as shown in Figure 4.7-4. You can choose whether to stake out point by point or based on cross-section data. If you choose point-by-point, you need to set the calculation method, whether by whole station number or whole station distance, the distance interval, and whether to automatically stake out the nearest point.

Click "OK" to enter the line stakeout menu, as shown in Figure 4.7-5, where you can stake out the nearest point, the previous point, the next point, etc., through the menu.

Staking out points by point-by-point sometimes requires staking out points beyond the calculated ones. To stake out a specific point by specifying the mileage and offset, click  to add stakeout as shown in Figure 4.7-6.

Lines Database			
1	L1		
Mile...	0.000	azi...	200°23'41"

Line parameters

Name	L2
Start Station	26.113
Input Type	Start Point+End Point
Set Start Point	  
Name	t3
North	2562917.758
East	441787.826
Height	17.334
Set End Point	  
Name	t4
North	2563014.288
East	441794.819
Height	18.121
Add parallel line	

Lines Database			
1	L1		
Mile...	0.000	azi...	200°23'41"
2D	26.113	3D	26.113
2			
Mile...	26.113	azi...	4°08'37"
2D	96.783	3D	96.786

Add Edit Delete OK

Figure 4.7-1

OK


Figure 4.7-2

Insert Edit Delete OK

Figure 4.7-3

Stakeout Settings

Setting out by pile by coordinate	
Automatic Stakeout Latest Point	
Target station	26.113
Range	26.113 ~ 122.896
Calculate Mode	Stakeout by station number
Spacing(m)	10



OK

Figure 4.7-4

Add Peg

Add Stake Mode	Calculate coordinates by mileage and offset distance
Mileage	26.113
Offset	0
Add the lofting coordinates to the coordinate point library	

Cancel OK

Figure 4.7-5

Figure 4.7-6

4.8 Elevation Control

Click on "Survey" -> "Elevation Control" to enter the surface library, as shown in Figure 4.8-1. Surface staking involves staking out designed surfaces recorded in the surface library for on-site stakeout, allowing real-time staking for cut and fill operations, among other applications.

Surface library management allows for adding, editing, deleting, and importing surface data. To create a new surface, as shown in Figures 4.8-2 and 4.8-3, choose the data type and create or import the surface data file accordingly.

Once a surface is selected from the list, as shown in Figure 4.8-4, click on "OK" to enter the surface staking, depicted in Figure 4.8-5.



Click  to enter the staking setting, as shown in Figure 4.8-6. In addition to measurement setting, information bar setting, and toolbar setting similar to those in point measurement, you can also configure options such as hiding the triangular mesh and lifting the reference surface.

	Name	Type
0	M1	Triangulation

Add Edit Delete Import OK

Figure 4.8-1

Point Coordinates	
Name	t6
x1	2563154.803
y1	441670.117
h1	19.385
Point Coordinates	
Name	t7
x2	2563148.178
y2	441558.261
h2	19.432
Point Coordinates	
Name	t8
x3	2563064.214
y3	441632.112
h3	18.656

Cancel OK

Figure 4.8-2

Import File

Internal Storage/tSurvey2.0/Import

Return

Triangulation File (*.SJW, *.XML, *.DXF)

Elevation file (*.TIN)

Triangulation File (*.SJW, *.XML, *.DXF)

Figure 4.8-3




Figure 4.8-4




Figure 4.8-5




Figure 4.8-6

4.9 Road Stakeout

Click "Survey" -> "Stake Road" to enter the road library, as shown in Figure 4.9-1. The road design staking function involves designing a route file based on elements such as road alignments, vertical curves, breaks, standard cross-sections, clear zones, widening, and slopes. With the designed route file and GNSS satellite positioning, various applications related to road alignment, cross-section data collection, and other tasks in road construction and surveying can be performed. This is suitable for surveying and collecting data for various levels of roads, railways, and other linear projects, as well as for tasks like construction and acceptance of road alignments.

For easy road design editing, the software supports the import of roads in various formats, as shown in Figure 4.9-2.

Road design, as shown in Figure 4.9-3. The road design elements include horizontal curves, vertical curves, chain breaks, standard cross-sections, and slopes. The standard cross-section includes data for super elevation and widening of the cross-section blocks.

1. Horizontal Curve Design: As shown in Figure 4.9-4. The horizontal curve is the centerline of the road, representing the overall alignment of the road. Methods for designing horizontal curves

include the element method, intersection method, and coordinate method. All roads are composed of road starting points, straight lines, transition curves, and circular curves. The element method involves directly inputting the elements of the road, where the starting point includes the starting mileage and coordinates, the straight line includes the initial bearing and length of the element, the transition curve includes the initial bearing, the radius, and the length from the starting point to the endpoint, and the circular curve includes the initial bearing, radius, and length. In the element method, the endpoint bearing of one element is usually equal to the starting bearing of the next element, and the radius connecting the transition curve to the straight line has an infinite value. The radius connecting the transition curve to the circular curve is equal to the radius of the circle. The intersection method calculates the combination of road design elements through the coordinates of control points, the length of transition curves corresponding to control points, parameters of transition curves, and circle radius using a certain algorithm. The coordinate method calculates the combination of road design elements through the coordinates of points on the road and the radius of circular arcs before each coordinate point, using a specific algorithm. Roads generated by the coordinate method only have starting points, straight lines, and circular arcs, forming a simplified road without transition curves.

2. Vertical Curve Design: As shown in Figure 4.9-5. The vertical curve represents the elevation changes of the centerline of the road at various mileages. It is the designed height of the centerline of the road, and it requires inputting the elevations corresponding to various mileages of the road's slope change points and the radii of the corresponding circular arcs of the slope change points. The software calculates the elevation values of the road at various mileages based on these design elements.

3. Gap Design: As shown in Figure 4.9-6. During the road design process, there are situations where a pre-designed road cannot be constructed due to unfavorable construction conditions or high costs. In such cases, it becomes necessary to make local modifications to the road design. After modifying the road, the road may become longer or shorter. To ensure that the design mileage data after the modification remains unchanged, the gap feature is used, which can be either a long gap or a short gap. A new mileage value is started at a certain mileage point, keeping the mileage data after this point unchanged.

4. Standard Cross-Section Design: As shown in Figure 4.9-7. In actual road construction, the centerline of the road is only the planned direction of the road, and the actual road includes various sections for motorized lanes, non-motorized lanes, green belts, sidewalks, etc. These sections are

collectively designed with parameters such as width and slope, referred to as the standard cross-section. In real road construction, due to environmental conditions, it is often impossible to build according to the standard cross-section. Sometimes, a section may need to widen or narrow at a certain point, or due to excessive road curvature, the slope may need to be increased at a certain location for safety reasons. Here, parameters for super-elevation and widening of the cross-section blocks are set. Super-elevation and widening are set based on the needs of each block, adding changes in mileage as needed.

5. Slope Design: As shown in Figure 4.9-8. In the actual road construction process, besides constructing the main road, the road may pass through terrain with significant elevation differences, such as mountains or lakes. If cutting through a mountain causes the mountain to collapse and damage the road, it is necessary to construct slopes for the mountain and embankment according to certain standards to protect the road.

After the road is designed with the above elements, it becomes a complete road design. Sometimes, different construction units only need basic parts and may not have all the design data. Users can design based on their actual project needs. Once the road is designed, it can be used for construction using the road design file.

Road Stakeout: Carrying out construction operations based on the designed road route file, as shown in Figure 4.9-9. Click "Apply," as shown in Figure 4.9-10, to access the stakeout menu and operations similar to point stakeout and line stakeout. Click  in the bottom right corner, as shown in Figure 4.9-11, to view cross-sectional diagrams of road construction.

Click , as shown in Figure 4.9-12, to switch to other stakeout modes, including point-by-point stakeout, road stakeout, cross-section stakeout, and other road stakeout-related operations

Cross-section measurement involves collecting elevation data at certain mileage intervals along the road route and its surroundings. This data is used for preliminary survey work in road construction, calculating earthwork volumes, and assessing construction costs.





Figure 4.9-1

Figure 4.9-2

Figure 4.9-3

Centerline		
Road Design	Intersection method	
BP	N:3407147.585	E:523357.57
K:368350	LS1:0	LS2:0
LineL:0	R:0 A1:0 A2:0	
JD1	N:3407175.105	E:523230.604
K:368479.914	LS1:0	LS2:35
LineL:74.08	R:628.228 A1:0 A2:148.283	
JD2	N:3407180.146	E:523096.714
K:368613.607	LS1:35	LS2:50
LineL:0	R:107.708 A1:61.399 A2:73.385	
JD3	N:3407288.411	E:522991.626
K:368759.743	LS1:40	LS2:40
LineL:0	R:60 A1:48.99 A2:48.99	
JD4	N:3407167.895	E:522875.326
K:368897.305	LS1:35	LS2:35
LineL:0	R:80.669 A1:53.136 A2:53.136	
JD5	N:3407236.118	E:522769.939
K:369006.531	LS1:0	LS2:0
LineL:0	R:768.457 A1:0 A2:0	
JD6	N:3407262	E:522718.683
K:369063.873	LS1:0	LS2:0
LineL:0	R:1746.431 A1:0 A2:0	
JD7	N:3407323.642	E:522602.064
K:369195.78	LS1:35	LS2:35
<input type="button" value="Add"/> <input type="button" value="Edit"/> <input type="button" value="Delete"/> <input type="button" value="Calculate"/>		
<input type="button" value="Add"/> <input type="button" value="Edit"/> <input type="button" value="Delete"/> <input type="button" value="Import"/> <input type="button" value="OK"/>		

Figure 4.9-4

Broken station		
1	Before station:368993.621	
Short	After station:369000.000	
	length:6.379	
2	Before station:100.000	
Long	After station:50.000	
	length:50	
<input type="button" value="Add"/> <input type="button" value="Edit"/> <input type="button" value="Delete"/> <input type="button" value="OK"/>		

Figure 4.9-5

Vertical Profile Database		
200.000	R: 30	T: 0
50	I1: 0%	I2: 0%
400.000	R: 60	T: 0
100	I1: 0%	I2: 0%
<input type="button" value="Add"/> <input type="button" value="Edit"/> <input type="button" value="Delete"/> <input type="button" value="Import"/> <input type="button" value="OK"/>		

Figure 4.9-6

← Standard Cross Section

Left section		Right section	
Left-1			
Width	100	Slope	30
Elevation Diff			

Add Edit Delete OK

← Slope section Library

Fill	Cut
1	Name s1
Level Count	1
Horizontal distance 8...	

Add Edit Delete OK

← Stake road

1 S2-4
Intersection method
/storage/emulated/0/tSurvey2.0/Project/ZY//Data/S2-4.rpm

✓ Apply
Edit
Delete

New Import

Figure 4.9-7

Figure 4.9-8

Figure 4.9-9



Figure 4.9-10



Figure 4.9-11




Figure 4.9-12

4.10 PPK Survey

Click "Survey" -> "Stop&Go", as shown in Figures 4.10-1, 4.10-2, and 4.10-3. This function utilizes post-processed kinematic (PPK) GNSS positioning technology based on carrier phase differentials. It falls under dynamic post-processing measurement techniques. This technology employs dynamic initialization On the Flying (OTF) for fast resolution of integer ambiguities. During field measurements, observing for 10 to 30 seconds is sufficient to calculate centimeter-level spatial three-dimensional coordinates. With this feature, you can directly measure and collect points without establishing a real-time communication link between the rover station and the base station. After completing field observations, you can perform post-processing on the raw observation data collected by the GNSS receivers on the rover and base stations. This process calculates the three-dimensional coordinates of the rover station.






Figure 4.10-1



Figure 4.10-2



Figure 4.10-3

4.11 Survey Settings

Click on "Survey"->"Survey Settings", as shown in Figure 4.11-1. This function allows you to set a coordinate range and, during field survey operations, it will monitor in real-time whether the

current position is within the set survey area. If the position exceeds this range, the user will be notified to avoid working outside the designated area.

The survey area can be managed by adding coordinates or selecting points in bulk from the point database, as shown in Figure 4.11-2. You can also import or export the coordinates of the survey area. The approximate shape of the survey area can be previewed on a map, as shown in Figure 4.11-3.



Figure 4.11-2: Point Coordinates screen. It shows a message 'Please set coordinate point' with icons for location, list, and map. The point details are as follows:

Name	t1
North	2562960.967
East	441716.32
Height	17.074




Figure 4.11-1

Figure 4.11-2

Figure 4.11-3

4.12 Layers Settings

Click on "Survey."-> "Layers Settings", as shown in Figures 4.12-1, 4.12-2, and 4.12-3. This function allows you to import background maps as reference base maps for survey operations, supporting formats such as dxf/dwg, shp, xml, and others.



Figure 4.12-1




Figure 4.12-2



Figure 4.12-3

4.13 AR Stakeout (WiFi communication mode required)

AR stakeout requires **WiFi connection to an instrument with AR functionality** for display. It provides a high-definition, real-world stakeout experience, offering more accurate AR-based stakeout to help you achieve precise pole placement in one go.

1. Click on "Device"->"Communication" to enter the communication settings interface, as shown in Figure 4.13-1. Select the instrument type (RTK) and **communication mode (WiFi)**, then click "Search", as shown in Figure 4.13-2, to view the list of WiFi devices. Select the corresponding device serial number (default device number), and click "Connect" to complete the device connection, as shown in Figure 4.13-3. Once the connection is successful, you will return to the main instrument interface.

2. Configure the rover station to achieve a fixed solution status, as referenced in Section 3.2.

Note: For using the controller network, the controller must have a SIM card inserted for internet access.

3. Click on "Survey"->"Point Stakeout" to enter the stakeout point database interface, as shown in Figure 4.13-4. The database will display un-staked and already staked points. Click on a point to

edit, view details, stakeout, or delete it, as shown in Figure 4.13-5. After selecting a point for stakeout, you will enter the point stakeout interface, as shown in Figure 4.13-6. Click the tilt

measurement icon at the top left  to enable the tilt measurement feature, as shown in Figure

4.13-7, and the icon will change to  when the feature is enabled. Then follow the on-screen prompts and input the antenna height (pole height), as shown in Figure 4.13-8. At this point, with the instrument in a fixed solution state, shake the pole back and forth for 5-10 seconds, then rotate

90°, and continue shaking the pole until the measurement icon changes to , as shown in Figure

4.13-9. Click the AR icon at the top left , as shown in Figure 4.13-10, to enter the AR real-world stakeout. Follow the arrow direction and distance indicators to navigate near the stakeout point, as shown in Figure 4.13-11. When the tip of the pole overlaps with the marked point, as shown in Figure 4.13-12, the AR real-world stakeout is complete. At this point, you can click the measurement icon and follow the prompts to choose to stake out the next point, the previous point, or re-stake.




Figure 4.13-1



Figure 4.13-2




Figure 4.13-3




Figure 4.13-4




Figure 4.13-5



Figure 4.13-6




Figure 4.13-7




Figure 4.13-8



Figure 4.13-9



Figure 4.13-10



Figure 4.13-11




Figure 4.13-12

4.14 Laser Survey

Laser measurement requires connection to an instrument with laser functionality to display. It is a more convenient and efficient point measurement method—wherever the laser points, you can measure that location, allowing you to measure across obstacles and save time and effort. When connected to an instrument with laser functionality, an additional laser measurement icon will appear on the survey interface. When the laser measurement interface is opened, the instrument will emit a green laser. The location illuminated by the laser can be measured for coordinates.

Click on "Survey" -> "Laser Survey" to enter the laser measurement interface, as shown in Figure 4.14-1. Follow the prompts and input the antenna height (pole height) based on the actual situation, as shown in Figure 4.14-2. At this point, the instrument needs to be in a fixed solution

state, as shown in Figure 4.14-3. Click the icon , follow the animated instructions, as shown in Figure 4.14-4, and shake the pole back and forth for 5-10 seconds, then rotate it 90° and continue

shaking it until the measurement icon changes to , as shown in Figure 4.14-5. Click the icon to complete laser measurement data collection. In this interface, you can name and code

the laser measurement points, view the laser measurement distance, and check the measurement accuracy.

Click "Point Database" to view both laser measurement points and regular measurement points, as shown in Figure 4.14-6.




Figure 4.14-1




Figure 4.14-2




Figure 4.14-3




Figure 4.14-4




Figure 4.14-5




Figure 4.14-6

4.15 Photogrammetry (WiFi communication mode required)

Photogrammetry combines RTK positioning technology with close-range photogrammetry, leveraging the high real-time accuracy of RTK and the efficiency and richness of photogrammetric results. Without the need for fixed stations or control points, this method effectively addresses signal issues in RTK surveying environments and the reliance on control points in photogrammetry. It allows for quick data processing, and after completion, selecting a point on the photo provides the 3D coordinates of that point.

1. Click on "Device"->"Communication" to enter the communication settings interface, as shown in Figure 4.13-1. Select the instrument type (RTK) and **communication mode (WiFi)**, then click "Search", as shown in Figure 4.13-2, to view the WiFi device list. Select the corresponding device serial number (default device number) and click "Connect" to complete the device connection, as shown in Figure 4.13-3. Once connected, you will return to the main instrument interface.
2. Configure the rover station to achieve a fixed solution status, as referenced in Section 3.2.

Note : To use the controller's network, the controller must have a SIM card inserted for internet access.

3. **Photogrammetry requires the tilt feature to be enabled for proper use.** It is recommended to enable the IMU in the point measurement interface to complete initialization, as referenced in Section 4.2.

4. Click on "Survey"->"Photogrammetry" to enter the photogrammetry interface, as shown in Figure 4.15-1. Click the input box next to the task name to customize the task name. Click on the antenna parameters to modify the antenna height (pole height) based on the actual situation. When

the image appears on the interface, click the auto-photograph button at the bottom center,  as shown in Figure 4.15-2, to begin photogrammetry. When the progress bar reaches 5 or more images,

click the stop button  as shown in Figure 4.15-3, and a prompt will indicate that data

processing was successful. Click the image library button on the bottom left  ,as shown in Figure 4.15-4, to enter the image management interface. Select the folder from the recent photographs to automatically enter the processing interface, as shown in Figure 4.15-5. In the images, select feature points by moving the image left or right, or zooming in and out, as shown in

Figure 4.15-6, to more accurately select the points for processing. When you find the desired point, click "Select" to process the point, as shown in Figure 4.15-7. If successful, the corresponding coordinate information will appear in the middle of the interface. Click "Save" to store the coordinates in the point database. If the selected point in the first image fails to process, try switching to other images, as shown in Figure 4.15-8. Once point processing is complete, click "Point Database" to check the photogrammetric point information in the coordinate point database, as shown in Figure 4.15-9.




Figure 4.15-1




Figure 4.15-2



Figure 4.15-3




Figure 4.15-4




Figure 4.15-5




Figure 4.15-6




Figure 4.15-7




Figure 4.15-8




Figure 4.15-9

5. Tools

In the software menu, click "Tools", as shown in Figure 5-1. The "Tools" menu includes functions such as coordinate converter, file conversion, angle converter, perimeter and area, volume calculation, post-measurement correction, file sharing, offset point, coordinate inverse calculation, point line calculation, center of a circle, averaging, spatial distance, and more.



Figure 5-1

5.1 Coordinate Converter

Click "Tools" -> "Coordinate Converter", as shown in Figures 5.1-1, 5.1-2, and 5.1-3. Use the coordinate system parameters set in the current project to convert source coordinates to target coordinates as needed. Click to choose a point from the point library or click to measure a new point for calculation. Clicking "Save" will also save the conversion result to the point library.

← Coordinates Converter

Source Coordinate   

Type	<input checked="" type="radio"/> BLH <input type="radio"/> XYZ <input type="radio"/> NEZ
Name	t1
Latitude	23°09'55.188082"
Longitude	113°25'50.932763"
Altitude	17.074

Target Coordinate

Type	<input type="radio"/> BLH <input checked="" type="radio"/> XYZ <input type="radio"/> NEZ
X	-2332940.686
Y	5383162.828
Z	2493569.686

← Coordinates Converter

Source Coordinate   

Type	<input checked="" type="radio"/> BLH <input type="radio"/> XYZ <input type="radio"/> NEZ
Name	t1
Latitude	23°09'55.188082"
Longitude	113°25'50.932763"
Altitude	17.074

Target Coordinate

Type	<input type="radio"/> BLH <input checked="" type="radio"/> XYZ <input type="radio"/> NEZ
North	2562960.967
East	441716.32
Height	17.074

← Coordinates Converter

Source Coordinate   

Type	<input type="radio"/> BLH <input checked="" type="radio"/> XYZ <input type="radio"/> NEZ
Name	t1
X	-2332940.686
Y	5383162.828
Z	2493569.686

Target Coordinate

Type	<input type="radio"/> BLH <input type="radio"/> XYZ <input checked="" type="radio"/> NEZ
North	2562960.967
East	441716.32
Height	17.074

Transform

Save

Transform

Save

Transform

Save

Figure 5.1-1

Figure 5.1-2




Figure 5.1-3

5.2 File Conversion

Click "Tools" -> "File Conversion", as shown in Figure 5.2-1. Use the coordinate system parameters set in the current project to convert the source coordinate file to the target coordinate file as needed.

Click "File" and select the file format, as shown in Figure 5.2-2, to import the source coordinate file for conversion.

Click "Convert," select the file format, as shown in Figure 5.2-3, to export the converted target coordinate file.



Cancel

Transform

Format Manager

OK

Format Manager

OK

Figure 5.2-1

Figure 5.2-2

Figure 5.2-3

5.3 Angle Converter

Click on "Tools" -> "Angle Converter", as shown in Figure 5.3. Use this tool to transform angle display formats such as degrees, degrees and minutes, radians, etc. Select one input format, and the tool will calculate values in other formats.

Angle Converter

Format: dd°mm'ss.ssss"

dd°mm'ss.ssss" 131.452

Result

dd (Decimal)	131.452
dd.mmssss	131.27072
dd:mm:ss.ssss	131:27:07.2
Radian	2.29427020833159
Gon	146.057777778g
dd mm ss.ssss	131 27 07.2

Cancel Calculate

Figure 5.3

5.4 Perimeter and Area Calculation

Click on "Tools" -> "Perimeter and Area", as shown in Figure 5.4-1. You can perform operations such as moving up, moving down, adding, and deleting on coordinate points. Click on "Preview," as shown in Figure 5.4-2, to preview and view the shape of the polygon. Click on "Calculate," as shown in Figure 5.4-3, to obtain the corresponding perimeter and area.

Perimeter and Area

List Map

No.	Name	North	East
1	t9	2563061.444	441676.895
2	t8	2563064.214	441632.112
3	t7	2563148.178	441558.261
4	t6	2563154.803	441670.117
5	t5	2563103.008	441789.162
6	t4	2563014.288	441794.819
7	t3	2562917.758	441787.826
8	t2	2562936.491	441707.22
9	t1	2562960.967	441716.32

Add Edit Move up Move down Delete Calcul

Figure 5.4-1




Figure 5.4-2




Figure 5.4-3

5.5 Volume Calculation

Click on "Tools" -> "Volume Calculation", as shown in Figure 5.5-1. Click to select the calculation surface to enter the surface library, as shown in Figure 5.5-2. In the surface library, you can create, edit, delete, and import triangular network data. After selecting the calculation surface, input the reference elevation or choose a reference point or surface. Calculate the cut and fill volumes for the data on that surface, as shown in Figure 5.5-3.

← Earthwork calculation

Calculate data

Calculating area ➤

computing method

- Reference elevation
- Reference point
- Reference slope
- Reference surface

Reference height

Result

Preview Calculate New Edit Delete Import OK

Figure 5.5-1

← Triangle library

1 the bottom of the embankment

Path Internal Storage/Documents/document...

Calculate data ➤

Calculating area the bottom of the embankment.txt

computing method

- Reference elevation
- Reference point
- Reference slope
- Reference surface

Reference height

Result

Fill	339.3595m ³
Cut	106.9458m ³
Area before excavation(2D)	1856.7154m ²
Area before excavation(3D)	1857.8128m ²
Minimum elevation before excavation	1000000000.0000m
Maximum elevation before excavation	-1000000000.0000m
Reference elevation	274.0000m

Save Results

Preview Calculate New Edit Delete Import OK

Figure 5.5-2

← Earthwork calculation

Calculate data

Calculating area ➤

computing method

- Reference elevation
- Reference point
- Reference slope
- Reference surface

Reference height

Result

Fill	339.3595m ³
Cut	106.9458m ³
Area before excavation(2D)	1856.7154m ²
Area before excavation(3D)	1857.8128m ²
Minimum elevation before excavation	1000000000.0000m
Maximum elevation before excavation	-1000000000.0000m
Reference elevation	274.0000m

Save Results

Preview Calculate New Edit Delete Import OK

Figure 5.5-3

5.6 Correction after Measurement

Click on "Tools" -> "Add offset to points at specified period", as shown in Figure 5.6-1, Figure 5.6-2, and Figure 5.6-3. Use the differential data from a self-established base station. Usually, calibration is needed using known points to match the coordinates of the moving station with the actual coordinates. If no calibration was done before measurement, you can use known points to recalibrate.

← Add offsets to points at specified period →

Marker Point Calibration

dX	0
dY	0
dH	0

← Add offsets to points at specified period →

Known Point Coordinates

North	2562960.967
East	441716.32
Height	17.074

Current WGS84 Coordinates

Latitude	23°09'54.391331"
Longitude	113°25'50.616211"
Altitude	16.931

← Add offsets to points at specified period →

Marker Point Calibration

dX	24.51
dY	9.004
dH	0.143

Clear

Update

Calculate

Clear

Update

Figure 5.6-1

Figure 5.6-2

Figure 5.6-3

5.7 File Sharing

Click "Tools" -> "Share File", as shown in Figure 5.7-1 and Figure 5.7-2. Choose the file you want to share and share it through the system's pop-up options.



Figure 5.7-1




Figure 5.7-2

5.8 Eccentric Point

Click "Tools" -> "Offset Point", as shown in Figures 5.8-1 and 5.8-2. Given the coordinates of the starting point A and the ending point B, with angle A=a and AP=L1, calculate the coordinates of point P, and save the result to the point library.

Offset Point

Line L1,Angle α

L1	50
α	13°14'52"
Azimuth reference direction	Reference point direction
Point A	
Name	t1
North	2562960.967
East	441716.32
Point B	
Name	t2
North	2562936.491
East	441707.22

Calculate

Figure 5.8-1

Result


Name	p4
Code	2PointDistanceAngle
North	2562919.341
East	441688.62
Height	16.807

Figure 5.8-2

5.9 Azimuth Distance

Click "Tools" -> "Coordinate Inverse Calculation", as shown in Figures 5.9-1 and 5.9-2. Use this function to select or collect the coordinates of two points and calculate the corresponding planar distance, azimuth, elevation difference, slope ratio, slope angle, and spatial distance.

← Coordinate inverse calculation



Note: Known point A and B. Calculate the AB(2D), A->B Azimuth(α), Elevation difference, Ratio of slope, Slope angle, AB(3D).

Coordinates Type	Local Coordinate
Set Start Point	
Name	t3
North	2562917.758
East	441787.826
Height	17.334
Set End Point	
Name	t4
North	2563014.288
East	441794.819
Height	18.121

Calculate

← Result



Result

Distance 2D	96.783
Azimuth	4°08'36.5482"
Elevation difference	0.787
Ratio of slope	0.8131596023431547%
Slope angle	0°27'57.2251"
Distance 3D	96.786

Close

Figure 5.9-1

Figure 5.9-2

5.10 Point-Line Calculation

Click "Tools" -> "Point Line Calculation", as shown in Figures 5.10-1 and 5.10-2. Input/select three known points, calculate the distance, perpendicular distance, deflection angle, corner, etc., and save the result to the point library.

← Point line calculation

Set Start Point

Name	t5
North	2563103.008
East	441789.162

Set End Point

Name	t6
North	2563154.803
East	441670.117

Set Offset Point

Name	t7
North	2563148.178
East	441558.261

Calculate

Figure 5.10-1

← Result

Result

AC	235.278
BC	112.052
AP	229.75
BP	99.925
CP	50.701
α	(Left)12°26'40.4093"
β	(Left)26°54'10.1168"

Close

Figure 5.10-2

5.11 Three-Point Circle Center


Click "Tools" -> "Center of Circle", as shown in Figures 5.11-1 and 5.11-2. Input/select three known points, calculate the center of the circle passing through these three points, and save the result to the point library.

← Center of circle

Note: Known point A and B and C, Calculate point O.

Point A			
Name	t8		
North	2563064.214		
East	441632.112		
Point B			
Name	t9		
North	2563061.444		
East	441676.895		
Point C			
Name	t1		
North	2562960.967		
East	441716.32		

Calculate



Save

Close

Figure 5.11-1

Figure 5.11-2

5.12 Average Value Calculation

Click "Tools" -> "Average", as shown in Figures 5.12-1 and 5.12-2. Calculate the average value of N points and save the result to the point library.

Average					Clear
No.	Name	North	East	Height	
1	t9	2563061.444	441676.895	18.892	
2	t8	2563064.214	441632.112	18.656	
3	t7	2563148.178	441558.261	19.432	
4	t6	2563154.803	441670.117	19.385	
5	t5	2563103.008	441789.162	19.354	
6	t4	2563014.288	441794.819	18.121	
7	t3	2562917.758	441787.826	17.334	
8	t2	2562936.491	441707.22	16.931	

Add Edit Delete Calculate

Figure 5.12-1




Figure 5.12-2

5.13 Spatial Distance

Click "Tools" -> "Great-circle Distance", as shown in Figures 5.13-1 and 5.13-2. Input/select two known points and calculate the spatial distance.

← Great-circle distance



Note: Known latitude, longitude and altitude for point A and B. Calculate the great-circle distance of AB.

Set Start Point

Name	t1
Latitude	23°09'55.188082"
Longitude	113°25'50.932763"
Altitude	17.074

Set End Point

Name	t2
Latitude	23°09'54.391331"
Longitude	113°25'50.616211"
Altitude	16.931

Calculate





Figure 5.13-1

Figure 5.13-2

5.14 Angle Calculation

Click "Tools" -> "Two Lines Angle", as shown in Figures 5.14-1 and 5.14-2. Input/select four known points and calculate the angle.

Two lines angle



Enter the points A, B, C, D on the two straight lines as shown in the figure, and calculate the included angle in the figure α .

Point A	<input type="button" value=""/>	<input type="button" value=""/>	<input type="button" value=""/>
Name	<input type="text" value="t3"/>		
North	<input type="text" value="2562917.758"/>		
East	<input type="text" value="441787.826"/>		
Point B	<input type="button" value=""/>	<input type="button" value=""/>	<input type="button" value=""/>
Name	<input type="text" value="t4"/>		
North	<input type="text" value="2563014.288"/>		
East	<input type="text" value="441794.819"/>		
Point C	<input type="button" value=""/>	<input type="button" value=""/>	<input type="button" value=""/>
Name	<input type="text" value="t5"/>		
North	<input type="text" value="2563103.008"/>		
East	<input type="text" value="441789.162"/>		
Point D	<input type="button" value=""/>	<input type="button" value=""/>	<input type="button" value=""/>
Name	<input type="text" value="t6"/>		
North	<input type="text" value="2563154.803"/>		
East	<input type="text" value="441670.117"/>		
<input type="button" value="Calculate"/>			

Figure 5.14-1





Figure 5.14-2

5.15 Intersection Calculation

Click "Tools" -> "Intersection Calculation", as shown in Figures 5.15-1 and 5.15-2. Find the intersection point of two lines and save the result to the point library.

Intersection calculation




Note: Known point A, B (on the first straight line) and C, D (on the second straight line). Calculate the coordinate of intersectional point P.

Point A			
Name	t6		
North	2563154.803		
East	441670.117		
Point B			
Name	t7		
North	2563148.178		
East	441558.261		
Point C			
Name	t8		
North	2563064.214		
East	441632.112		
Point D			
Name	t9		
North	2563061.444		
East	441676.895		
Calculate			

Figure 5.15-1

Result



Name	p4
Code	IntersectionPoint
North	2563109.341
East	440902.539
Height	19.162
Result	
Angle	6°55'44.4182"
Save Close	

Figure 5.15-2

5.16 Backward Intersection


Click "Tools" -> "Resection", as shown in Figures 5.16-1 and 5.16-2. Given two points and their distances to the target, determine the target point and save the result to the point library.

Resection

Note: Known point A and B, know distance L1 and L2. Calculate point P.

Line L1,L2	
L1	30
L2	60
Point A	
Name	t1
North	2562960.967
East	441716.32
Point B	
Name	t2
North	2562936.491
East	441707.22

Calculate



Save **Close**

Figure 5.16-1

Figure 5.16-2

5.17 Forward Intersection

Click "Tools" -> "Forward Intersection", as shown in Figures 5.17-1 and 5.17-2. Given two points and their included angle, determine the target point and save the result to the point library.




Figure 5.17-1

Figure 5.17-2

5.18 Offset Point Calculation

Click "Tools" -> "Offset Point Calculation", as shown in Figures 5.18-1 and 5.18-2. Given two points, calculate the coordinates of the corresponding mileage and offset positions, and save the result to the point library

← Offset point calculation

Note: Known point A and B, known distance AP(L1), known perpendicular offset distance L2. Calculate point P.

Set Start Point	
Name	t5
North	2563103.008
East	441789.162
Set End Point	
Name	t6
North	2563154.803
East	441670.117
Parameter Settings	
Mileage	60
Offset	30

Calculate

Figure 5.18-1

← Result

Name	p4
Code	OffsetPoint >
North	2563154.455
East	441746.113
Height	19.368

Save Close

Figure 5.18-2

5.19 Midpoint Calculation

Click "Tools" -> "Equal Point Calculation", as shown in Figures 5.19-1 and 5.19-2. Input two known points, calculate the midpoint of the line segment, and save each midpoint to the point library.

← Equal point calculation

Set Start Point

Name	t7
North	2563148.178
East	441558.261
Height	19.432

Set End Point

Name	t9
North	2563061.444
East	441676.895
Height	18.892

Parameter Settings

Number of segmentation	10
Start Mileage	10

Calculate

Figure 5.19-1




Figure 5.19-2

5.20 Extension Point Calculation

Click "Tools" -> "Extend Point Calculation", as shown in Figures 5.20-1 and 5.20-2. Input two known points, calculate points along the extended line, and save the result to the point library.

← Extend point calculation

Note: there is a point P on the extension line of straight line AB, given the coordinates of point a and B, BP = L1, calculate the coordinates of point P.

Use Z

Point A			
Name	t1		
North	2562960.967		
East	441716.32		
Point B			
Name	t2		
North	2562936.491		
East	441707.22		
L1	15		

Calculate

← Result

Name	p4
Code	ExtendPoint >
North	2562922.431
East	441701.993
Height	0

Save Close


Figure 5.20-1

Figure 5.20-2

5.21 Vertical Distance Calculation

Click "Tools" -> "Vertical Distance Calculation", as shown in Figures 5.21-1 and 5.21-2. Input/select three known points, calculate the perpendicular foot and distance, and save the result to the point library

← Vertical distance calculation



Description of vertical distance calculation: given the coordinates of points a and B on the straight line AB and the coordinates of point C outside the straight line, calculate the vertical distance L between point C and straight line AB and the coordinates of vertical point P.

Point A	
Name	t3
North	2562917.758
East	441787.826


Point B	
Name	t4
North	2563014.288
East	441794.819

Point C	
Name	t5
North	2563103.008
East	441789.162

Calculate

Figure 5.21-1

← Result



Result	
Name	p4
Code	PedalPoint >
North	2563102.137
East	441801.183
Height	0

Result	
Vertical distance L	12.053

Save Close

Figure 5.21-2